

DJI Enterprise Livestream Integration Details:


Through the integration between our systems, AirWise and DJI customers can easily use DJI aircraft with AirWise products for Livestreaming.

To setup DJI aircraft for Livestream please follow the instructions below:


DJI Pilot 2 App

DJI aircraft using the Pilot 2 App will be able to transmit both Livestream and telemetry data. To setup the DJI Cloud please follow the instructions below:


- 1) Make sure the Aircraft is powered on and connected to the controller.
- 2) Click on the Cloud Icon for 'Cloud Service' in the DJI Pilot 2 Application



- 3) Click on the Open Platforms Option




- 4) Type in the following URL: <https://live.flightmanager.app/dji.html>



- 5) If you get a page not found check the internet and the URL to verify its correct.

- 6) Wait a few seconds and you should have 4 green boxes: Write down the Aircraft SN!




- 7) Then click the < icon to go back into the main Pilot 2 Menu.
- 8) If you have any Red box's then restart the process and make sure the drone and green status light is on.
- 9) Provide the AirWise Solutions Customer Success Team with:
- a) Your DJI Aircraft SN, it should look something like this, 1581F5FJB22A700A0G0Q
 - b) The AirWise Solutions Customer Success Team can be reached at support@airwisesolutions.com


DJI Pilot App

To setup Livestreaming on the DJI Pilot app:

1. Make sure the Aircraft is powered on and connected to the controller




3. Select Manual Flight




AIRWISE – DJI LIVESTREAM AND TELEMETRY SETUP GUIDE


4. Tap the 3 dots in the upper right corner of the screen




5. Tap the 3 dots at the bottom of the menu and select 'Live Stream'



- tap on the 'Customize Live Stream' link




- Enter the following RTMP address without the question marks:
<rtmp://live.flightmanager.app:1935/livedrone/???>
****You will need to replace the question marks ??? with the serial number of your DJI aircraft and tap 'OK'**




AIRWISE – DJI LIVESTREAM AND TELEMETRY SETUP GUIDE

8. Tap on 'OK' to begin the Live Stream
9. To end the Live Stream, tap the blue circle in the upper right corner of the screen



10. Tap the 'Stop Live Streaming' button



11. For future flights you will not need to enter the Live Stream Link. It will be remembered.

DJI Fly App V1.16.0 and Later

To setup Livestreaming on the DJI Fly app V1.16.0 and later:

1. When using DJI RC 2/DJI RC Pro/DJI Smart Controller for live streaming via DJI Fly, a microphone must be inserted to enable live streaming.
2. This includes the DJI Mini 4

DJI Avata 2 and Later

To live stream from your DJI Avata 2:

Step 1: Connect Your Devices

1. Connect the USB-C port of your DJI Goggles 3 to your mobile device using a USB-C OTG data cable.
2. Open the DJI Fly app on your smartphone.
3. Tap GO FLY at the bottom right corner of the screen to ensure the app detects and displays the drone's live camera feed.

Step 2: Configure the RTMP Settings

4. On the "GO FLY" screen, tap the three dots (...) in the top right corner to open the Settings menu.
5. Navigate to Transmission > Live Streaming Platforms.
6. Select RTMP.
7. Paste the RTMP Address (Stream URL and Stream Key combined, often separated by a forward slash /) into the RTMP address field.
8. Select your preferred resolution (e.g., 1080P or 720P) and bitrate. (Note: If your mobile connection is weak, 720p is recommended to avoid buffering).

Step 3: Go Live


9. Once the RTMP information is entered correctly, tap Start Livestream.
10. A 3-2-1 countdown will appear, and the stream will begin broadcasting to your platform's dashboard.

NOTE: Starting with **DJI Fly app version V1.16.0 and later**, an external microphone must be plugged into the USB-C port of controllers that lack a built-in microphone (such as the **DJI RC Pro**) whenever you attempt to livestream via **RTMP**. If no microphone is detected, the app blocks the stream and displays an error prompt.

UASidekick Video Livestream Integration Details:


To set up AirWise Sidekick for viewing Video Livestream from your drone(s) there are 3 steps that need to be taken.

- 1) Apply Livestream settings to the aircraft in your fleet
 - 2) Determine who the Viewers will be.
 - 3) Create Missions so Viewers can see the Livestreams
-
- 1) The first step is to apply the Livestream settings to the aircraft in your fleet. This can only be done by an Enterprise Administrator.
 - a. Click on the 'Nine-Dot' menu and then select 'Enterprise Admin'




AIRWISE – DJI LIVESTREAM AND TELEMETRY SETUP GUIDE


- b. Click on the 'Aircraft' tab and then select the aircraft to add Livestream



- c. Click the 'Edit' button




- d. If you're using the Pilot 2 app and want to transmit Telemetry data, be certain to enter the serial number of the aircraft in the 'Serial #' field EXACTLY as it was on the 'Aircraft SN Status' field of the flight controller.




AIRWISE – DJI LIVESTREAM AND TELEMETRY SETUP GUIDE


- e. Scroll down to the bottom of the Edit Aircraft window and click on the 'Add Livestream +' link




- f. Enter a name that describes the Livestream. This name will be displayed below the Livestream window.
- g. Enter the drone serial number in the 'ID' field. This serial number MUST match the serial number entered at the end of the RTMP address on the drone controller.
- h. Click the 'Save' button



- 2) The next step is determining who the viewers for the Livestream will be. There are two types, Pilots and invited Viewers. All of the Pilots in your organization are automatically eligible to be Livestream Viewers. You can also invite people other than pilots in your organization to be Livestream Viewers. They can either be from inside or outside your organization. The great part is you can invite as many as you want and they do not count against the number of seats your organization has purchased.
 - a. Click on the 'Users' tab of the 'Enterprise Admin' window
 - b. Click on the 'Viewers' sub-tab
 - c. Click on the 'Invite Viewer +' button




- d. Enter the email address for the viewer you would like to invite
- e. Click on the 'Save' button




The person you've invited will receive an email with a link to the AirWise Sidekick subscription page. They'll need to create a Viewer subscription by entering their Name, Email, Phone Number and creating a password. They will then be able to receive notification by email or text when the Livestream starts.

3) The last step is to create a Mission. Missions are where the Livestreams are actually viewed.

a. Click on the 'Missions' icon in the 'Nine-Dot' menu



b. Click on the 'Add Mission' button




c. Enter a name for the Mission. *This is a required field*


d. You can enter a description for the mission if you'd like.

e. You can select if the Mission is going to be Permanent or not. A permanent mission will always be visible by those with access to the mission. Create a permanent mission for viewers who need quick and always available access to a drone's livestream.


f. If the Mission is not Permanent, enter the date and time when the Mission begins along with the duration of the Mission in Days, Hours and Minutes.



- g. To select which Livestream will be available in the Mission, click on the Aircraft drop down menu and select. You can select as many Aircraft/Livestreams as you like.



- h. Select which Viewers you would like to add to the Mission by clicking on the 'Livestream Viewers' drop down menu.



- i. If you do not want the viewers to know when changes are made to the Mission select the check box next to 'Do not notify viewers of this change'
- j. Selecting the check box next to 'Notify viewers when the livestream starts' will allow all of the viewers to receive an email and/or text message when any of the Livestreams in the Mission begin.
- k. If you need to add any additional Viewers you can use the 'Invite Viewers' button in the lower left corner of the 'Add Mission' window.

AIRWISE – DJI LIVESTREAM AND TELEMETRY SETUP GUIDE

- I. Click the 'Save' button when all information has been entered.

The screenshot shows the 'Add Mission' dialog box in the Airwise application. The dialog is titled 'Add Mission' and has a purple header. It contains several sections: 'AIRCRAFT' with a dropdown menu, 'EXTERNAL LIVESTREAM LINK' with a text input field and a plus icon, 'LIVESTREAM VIEWERS' with a dropdown menu and a list of viewers (one named 'Orville Wright' is visible), and two checkboxes: 'Do not notify viewers of this change' and 'Notify viewers when the livestream starts'. At the bottom of the dialog are three buttons: 'Invite Viewer', 'Save', and 'Close'. A yellow arrow points from the left towards the 'Save' button, and another yellow arrow points from the 'Notify viewers when the livestream starts' checkbox down towards the 'Save' button.